



AY

Device Control

Used to select the component you want to operate and signals remote control activity.



Turns devices ON/OFF



Enables TV mode functions

On-Demand Control

Perform standard VCR and DVD functions when in VCR and DVD mode, and On-Demand functions when in cable mode.

Numeric Keys